Marine Weight Schedule - User Manual

Introduction

Marine Weight Schedule is a plugin for Rhino 3D designed to generate - from a vessel's 3D model - a bill of masses/inertias, as well as a Bill Of Materials. It take in account points, curves, surfaces, solids and blocks, and use the parameters from the layers names to apply the unitary/lineic/surfacic/volumic masses, with a margin percentage applied.

A command is also provided to generate an hydrostatic report at a given height interval (based on Rhino hydrostatics features)

Both reports will be generated as excel files (.xlsx) based on a customizable template, but microsoft excel doesn't need to be installed on the computer.


Plugin installation

Overview

The plugin installer can be downloaded at: https://www.tomkod.com/product/marine-weight-schedule/
A free trial is included, and yearly licenses can be purchased on the aforementioned page.
Marine Weight Schedule works for Rhino 6[1)] and Rhino7[2)].

Yak


Our plugins are also compatible with Yak, Rhino's new package manager [3)], which is basically an application store for Rhino. You just need to call Rhino's command ***_PackageManager***:



You can also install from the repository with the following command line:

```
"D:\Program Files\Rhino 6\System\Yak.exe" install 'PluginName'
```

If you add this in a batch file (*.bat) at windows startup, it is probably the best way to keep all your plugins up-to-date 😉



License activation

Prerequisites

The free evaluation can be used once per computer, and requires network access to www.license.tomkod.com
The license activation requires network access to www.tomkod.com
Please check your firewall in case of failure.


Activation form

The activation window automatically shows up when the plugin is loading and a valid license or trial is not registered. If you want to see, change or remove your license while the plugin is already loaded, you can use the Rhino commands ***PluginName*_License**.
Activation status is always visible on the upper right corner of the form, if the icon is green your plugin will be enabled:



Trial Tab


This first tab is dedicated to the trial requests. Your trial status is displayed, and the button is disabled if a trial is not available for your computer (Your trial has already been activated, or the server is unreachable)



Commercial Tab

This tab's two main buttons let you Check-out (Activate) or Check-in (Desactivate) your license from

our license server.




When the checkbox *"Enable floating licenses"* is checked, every TomKod's plugin will try to deactivate the license automatically when closing (Making it available for another of your computers)

Finally, a license certificate (*.TkLic) can be selected at the bottom of this tab. It allows to activate a license offline, but the license won't be floating anymore. If you need one, contact us at https://www.tomkod.com/contact/

Toolbar


The toolbars for Rhino are always included in your plugins installation directory, or can be downloaded here.
You just have to drag/drop the file "Tomkod.rui" to a rhino window to install them.



Features and commands

MWS_About

This command can be used only from the command line prompt. It displays the plugin's current revision and license status.



MWS_License

This command can be used only from the command line prompt. It displays the plugin's activation form.

See license_activation.


ProjectWeightReport

Computes the whole model masses, as well as a Bill Of Materials[4] and generates an excel report.

Walkthrough

For each layer[5], the command will retrieve the *Mass*, *Margin* and *Vertical offset* values from the layer name[6], then:

1. For each rhino object, the actual mass and gravity center will be computed, using the layer values. The layer's *Mass* will be used differently, depending on the object's type: ponctual mass for Points, lineic mass for curves, surfacic mass for surfaces[7], and volumic mass for closed polysurfaces.
2. At the same time, the Bill-of-Materials will be created internally.
3. An excel report will be created.



Model preparation

The fondamental idea of this plugin is to match data from the model's objects and their layer. For this reason, each layer should contain only one specific material. *For example:*

- The layer **`Deck1:SectionB:Nuts`** could contain only points, and the layer's *(mass)* information would be used as a ponctual mass for each nut.
- The layer **`Deck1:SectionB:plates`** could contain only surfaces, and the layer's *(mass)* information would be used as a surfacic mass for each plate.


Layers naming convention

The document's layers should follow the following naming convention:

```
LayerName (Mass) %Margin% |VerticalOffset|
```

where:

- **`Mass`** will be the ponctual/lineic/surfacic/volumic mass
- **`Margin`** (optional) will be the percentage to add to the object's mass.
- **`VerticalOffset`** (optional) will be the the vertical offset to apply to the layer's masses



Particular case for Stiffeners

A specific naming convention has been added to properly count the stiffeners in the Bill-of-Materials, to consider the scenarii explained below.

> Those particular cases only impact how materials will be counted in the Bill-of-Material tab. The weight report results won't be impacted.

- **Implicit stiffeners**


There are some cases where you don't want/need to create an actual geometry for your structure stiffeners, for example when you are at the early stage of your project. *Implicit stiffeners* let you count the required stiffener lengths relative to the layer's metal sheet's areas.

```
LAYERNAME:   MyLayerName (Mass) %Margin% |VerticalOffset| [StiffenerName s=value]
```

In the Bill-of-Material, this would create two outputs: an area for the surfaces in *"MyLayerName"*, and a length for their stiffeners.

> 'StiffenerName Length' = 'MyLayerName Area' / s

For example:



- **Stiffeners defined as curves in the model**

Two kind of curves-defined stiffeners can be used:

- Folded plates

```
LAYERNAME:   W:120x6 BF60
```

This will be counted as one surface, Thickness 6, width=120+60. Thus the result in the Bill-of-materials will be:



'Th.6 plate Area' = length x (120+60)

- Profile with flat plate

```
W:120x6 F:80x8
```

This will count as one surface, Thickness 6, width=120, plus one profile 80×8



In this case, the command will output an area for the plate, and a length for the profile:

'Th.6 plate Area' = length x 120

'80×8 profile length ' =length

- **Stiffeners defined as surfaces in the model**

In some cases, you might want to represent your stiffeners as a 3D surface in the model, but count them as lineic outputs in the Bill-of-Materials because they are technically profiles.

```
LAYERNAME:   F:80x8
```

This would output:



'80×8 profile Length' = area / 80

As for the weight estimate, the layer's optional %Tolerance% will be considered:

```
LAYERNAME:   F:80x8 |34.1| (87.2) %3.4%
```

This would output:

'80×8 profile Length' = (area / 80) + (area / 80) * 3.4/100

Particular case for Blocks


By default, rhino® blocks[8] are ignored by the command. However we provide several commands to transform blocks into GBlocks, which are considered in the reports as ponctual masses.

See gblock_setdata


When the command will process GBlocks, their layer properties will be ignored, and the Gblock's internal definition will be used instead (Name, gravity center, mass).

Output

When the whole model has been processed, an excel[9] report is generated, and the user is invited to pick a name and location for the resulting file. Bill of masses main sheet:



Bill of masses detailed sheets for Volumes, surfaces, curves and points:



TomKod
Softwares for users, by users

PROJECT : xxx
MASS SUMMARY-re0
Customer :


Last update: 18/02/2021 (13:49)

Reference : DEMO_ProjectWeightReport_v2.3dm

BILL OF VOLUMIC MASSES

Item	Volume (mm³)	Volumic mass (kg/m³)	Margins	Mass (kg)	Xg (mm)	Yg (mm)	Zg (mm)	Volumes inertia Izz (mm⁵)	Volumes inertia Iyy (mm⁵)	Volumes inertia Izz (mm⁵)	Masses inertia Izz (kg.mm²)	Masses inertia Iyy (kg.mm²)	Masses inertia Izz (kg.mm²)
Bi-Metal	4.13E+07	53	0.0%	2	-214	-5261	2958	8.23E+12	1.96E+15	1.97E+15	4.36E+05	1.04E+08	1.04E+08
Steel::Profiles::Round Ø20	2696208	7850	5.0%	22	-165	4874	4150	1.25E+12	1.93E+12	1.75E+12	1.03E+07	1.59E+07	1.44E+07
Float::Profiles::HP 120x6	1.45E+07	7850	5.0%	120	0	0	1691	1.81E+14	2.65E+15	2.83E+15	1.49E+09	2.19E+10	2.33E+10
Float::Profiles::HP 100x6	1.15E+07	7850	5.0%	95	-296	-469	1758	6.96E+13	8.70E+14	9.34E+14	5.74E+08	7.17E+09	7.70E+09
Float::Profiles::HP 200x10	2.51E+07	7850	5.0%	207	2	-807	1407	7.60E+13	3.00E+15	3.06E+15	6.27E+08	2.48E+10	2.52E+10
Float::Profiles::Round Ø30	7526622	7850	5.0%	62	0	-4874	2005	2.54E+12	2.49E+15	2.49E+15	2.09E+07	2.05E+10	2.05E+10
				507.8957	**-62.3991**	**-820.693**	**1739.091**				**4.76E+09**	**7.46E+10**	**7.88E+10**

Results | Volumes | Surfaces | Curves | Points | BillOfMaterials



TomKod
Softwares for users, by users

PROJECT : xxx
MASS SUMMARY-re0
Customer :

Last update: 05/01/2021 (15:13)


Reference : DEMO_ProjectWeightReport.3dm

BILL OF PONCTUAL MASSES

Item	Points quantity	Ponctual mass (kg)	Margins	Mass (kg)	Xg (mm)	Yg (mm)	Zg (mm)	Points inertia Izz (mm⁵)	Points inertia Iyy (mm⁵)	Points inertia Izz (mm⁵)	Masses inertia Izz (kg.mm²)	Masses inertia Iyy (kg.mm²)	Masses inertia Izz (kg.mm²)
Equipments // Tesla model R	2	2300	0,0%	4600	2291	294	3416	5810375	63113833	68924208	13363861587	145161816500	158525678088
Equipments // MissingData - Bike Harley	1	0	0,0%	0	0	0	0	0	0	0	0	0	0
Equipments::Rescue Boats	2	180	0,0%	360	0	-5041	3308	0	2,72E+08	2,72E+08	0,00E+00	4,89E+10	4,89E+10
				4960	**2124,514**	**-93,28**	**3408,451**				**2,29E+10**	**1,96E+11**	**2,1869E+11**

Results | Volumes | Surfaces | Curves | Points | BillOfMaterials

Bill of materials:



TomKod
Softwares for users, by users

PROJECT : xxx
MASS SUMMARY-re0
Customer :

Last update: 18/02/2021 (13:49)


Reference : DEMO_ProjectWeightReport_v2.3dm

BILL OF MATERIALS

LAMINATED PLATES		
F: 100x11	22994979.1	mm³
F: 100x8	3538524.77	mm³
F: 120x11	5090566.62	mm³
F: 150x11	5511497.29	mm³
Th.6	103378740	mm³
Th.8	255121521	mm³
EXTRUDED PROFILES		
100x10	16045.2844	mm
60x6	9000.91597	mm
80x10	53421.4513	mm
80x6	26671.4546	mm
OTHERS		
Equipments // Bike Harley	1	
Equipments // Tesla model R	1	
Rescue Boats	2	

Results | Volumes | Surfaces | Curves | Points | BillOfMaterials | ...

A custom ViewPort is created with the gravity center displayed:



Options

No option available.

Customization

The excel report template “PWE_Model.xlsx” can be modified in the plugin's install directory, usually:

%AppData%\McNeel\Rhinoceros\7.0\Plug-ins\Marine Weight Schedule for RH6-RH7 (dac6da37-23fc-4ad6-9b46-33a2cad9e13b)*VersionNumber*
(Adapt Rhino's version if needed, as well as the plugin's version)


It is recommended to edit only the texts values and the logos, while keeping the document general layout.

HydrostaticReport

Computes an hydrostatic analysis at different heights and generates an excel report.

Walkthrough

The hull's surface or polysurface is selected as input. Once validated, Rhino's hydrostatic culculation is runned at various heights as defined in options, and an excel report is generated.



CASE : xxx
Hydrostatique-rev0
Customer:

Last update: 09/10/2018 (18:40)
Reference : HULL.3dm

Density: 1,025

TE (mm)	Hull Volume (m3)	Displacement (Kg)	LCB (m)	TCB (m)	VCB (m)	Wet Surface (m²)	Lwl (m)	Bwl (m)	Floating Surface (m²)	LCF (m)	TCF (m)
0	0	0	0	0	0	0	0	0	0	0	0
400	104,716	107333,9	6,6647E-09	4,4018E-15	0,211786	309,518	28,931	11,0001	300,97	2,6666E-09	-1,7745E-14
800	234,389	240248,725	-4,4117E-08	2,0758E-09	0,42879	368,815	32,3866	11,2	341,889	-1,6783E-08	2,6562E-09
1200	377,207	386637,175	-1,2697E-07	3,7393E-09	0,646117	422,516	35,3723	11,2	371,786	-4,1417E-08	5,4739E-09
1600	531,539	544827,475	-1,3983E-07	6,3871E-09	0,865704	476,361	38,3579	11,2	399,569	-2,5545E-08	9,1985E-09
2000	696,379	713788,475	-1,2904E-07	9,0957E-09	1,0873	527,381	40	11,2	421,618	3,5812E-10	1,2235E-08
2400	0	0	0	0	0	568,751	0	0	0	0	0

Hydro

Options

TEMin	Minimum height (mm)
TEmax	Maximum height (mm)
Delta	Distance between two tested height (mm)
Density	Water Density
AutoMinMax	Detect TEMin and TEmax values from geometry (Only available when a geometry is selected)

Customization

The excel report template “Hydro_Model.xlsx” can be modified in the plugin's install directory, usually:

%AppData%\McNeel\Rhinoceros\7.0\Plug-ins\Marine Weight Schedule for RH6-RH7 (dac6da37-23fc-4ad6-9b46-33a2cad9e13b)*VersionNumber*
(Adapt Rhino's version if needed, as well as the plugin's version)

It is recommended to edit only the texts values and the logos, while keeping the document general layout.


GBlock_SetData

Add gravity center and mass informations to a block. GBlocks are considered by the command *ProjectWeightReport* , which makes them extremely useful for your equipements.

Walkthrough

1. Start the command
2. Pick a rhino block[10)] in the model
3. Pick the GBlock's gravity center

4. Enter the GBlock's mass
5. Enter the GBlock's name (By default, Rhino's block name is used)
6. Click OK or press Enter



GBlock_GetList

Lists every existing GBlock names and masses to the command line.

Walkthrough


Todo

GBlock_ReadData

Reads a GBlock data.

Walkthrough

1. Select a GBlock
2. The data is shown in the command line:



Gblock_Select

Select a block by their GBlock Name. (From a list of available GBlock names)

Walkthrough



Todo

GBlock_SelectNextMissingData

Select the next block in the document where gravity center and mass are undefined

Walkthrough



Todo

1)
Rhino6.15 or later
2)
Tested up to Rhino 7.1
3)
Rhino 6 or later only, with graphic user interface for Rhino7 only
4)
v1.0.4 and later versions
5)
The whole model or worksession will be used
6)
Read “Model preparation” below
7)
To avoid errors, openened polysurfaces won't be allowed
8)
instances references
9)
.xlsx
10)
Instance reference

From:
https://wiki.tomkod.com/ - **TomKod knowledge base**

Permanent link:
https://wiki.tomkod.com/doku.php?id=start:plugins:marineweightschedule:mws-usermanual&rev=1610016798

Last update: **2021/01/07 11:53**